

TAG DESCRIPTION TABLE

7700G-AV6aD1P0

06 January 2004

abbrchklist

Abbreviated Checklist

Description: Part of a safety supplement or operational supplement that contains information that affects the related abbreviated flight crew checklists.

Source paragraph: 7700G paragraph 3.2.7.4

Content Model: procedure*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

abbrsect

Abbreviation Section

Description: Identifies the paragraph used to define abbreviations/acronyms and the associated list.

Source paragraph: 4.3.4 & 4.5.9

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*), (abbrtitle?, acronymlist))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |

| | | | |
|-----------|-------------------------------------|----------|--|
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

abbrtitle

Abbreviation Title

Description: Identifies the title for the list of acronyms and abbreviations.

Source paragraph: 4.3.4 & 4.5.9

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)-(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

abnormflt

Abnormal Flight Characteristics

Description: Area of Section VI, Flight Characteristics

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.6.

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |

| | | | |
|----------|--|-----------------|--|
| deltype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

acronym

Acronym

Description: Identifies the first time an acronym or abbreviation is used in a chapter. The def part of the acronym is used to define the acronym/abbreviation, while the term part of the acronym contains the actual acronym/abbreviation. Within the text, the term portion will be surrounded with parenthesis.

Source paragraph: 4.3.4 & 4.5.9

Content Model: (def, term)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

acronymlist

Acronym/Abbreviation List

Description: Identifies the list of acronyms and abbreviations.

Source paragraph: 4.3.4 & 4.5.9

Content Model: ((term, def)*)-(acronym | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|----------------|----------------|---|
| rtermwidth | NUTOKEN | 2.5IN | Allows you to define the right term width. |
| ltermwidth | NUTOKEN | 1IN | Allows you to define the left term width. |
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |

action

Action

Description: Response to a checklist task

Source paragraph: paragraph 3.7.5.1

Content Model: ((#PCDATA|change|tabmat|ftnref|xref|verbatim|em-
phasis|applicabil|graphic|extref|dataiden|hcp|hci|esds|
nsp|oci|ocp|fcp|acronym|prindex|secindex|nameloc|clink|
ilink|object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

activity

Reporting Activity

Description: Identifies the activity submitting a technical publication deficiency report list.

Source paragraph: 4.5.9

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

additcont

Additional Continued

Description: Allows the figure and para elements to be repeated without causing a DTD conflict.

Source paragraph:

Content Model: (figure | para)+

apprland, climb, cruise, descent, endure, engdata, introduction, msnplan, pdtakeoff

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|---------------------|
| label | CDATA | #IMPLIED | Serves no function. |

address

Change Sheet Name/Address

Description: Identifies the name and address of the activity responsible for preparation of the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

adweather

Adverse Weather Operation

Description: Section VII of the flight manual.

Source paragraph: 7700G paragraph 3.3.9

Content Model: ((title), secttoc, para0+) +(figure | table | objmedia | sectocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|------------------------|----------|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

aircrewfm

Aircrew Flight Manual

Description: Part of the Status page that lists the basic flight manual, date, and change number and date.

Source paragraph: 7700G paragraph 3.2.8, 3.2.8.1 and Figure 2

Content Model: ((tonum, date, tochgnum, tochgdate)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

amplification

Amplification

Description: Explanatory/additional information for checklist items in the basic flight manual.

Source paragraph: 7700G paragraph 3.2.12.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex)+ | (randlist | deflist | seqlist))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

appendix

Appendix

Description: Identifies an appendix to the manual.

Source paragraph: 4.2.9.6

Content Model: (title, para0+) +(ftnote | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

applic

Applicability/Effectivity Definition Entry

Description: Defines applicability/effectivity markings.

Source paragraph: 4.3f & 4.5.9

Content Model: (term, def)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-----------|------------------|--|
| id | ID | #REQUIRED | Allows the author to generate a unique ID for use when referencing this entry. |

applicabil

Applicability/Effectivity

Description: Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicabilty/effectivity markings defined in the applicability definition (applicdef) to appear at that point in running text.

Source paragraph: 4.3f

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) - (applicabil | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|------------------|---|
| applicref | IDREFS | #REQUIRED | Allows you to assign an applicable reference to this element. |
| security | (U C S N) N | | Identifies security level of the document |

applicdef

Applicability/Effectivity Definition

Description: Identifies the paragraph used to define applicability/effectivity markings, and the associated list.

Source paragraph: 4.3f

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*), (applttitle?, applchd?, applic+))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|----------------|-----------------|---|
| rtermwidth | NUTOKEN | 2.5IN | Allows you to set the right term width. |
| ltermwidth | NUTOKEN | 1IN | Allows you to define the left term width. |
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |

| | | | |
|-----------|--|-----------------|--|
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

applichd

Applicabilty/Effectivity List Column Headings

Description: Defines the column headings used for the applicabilty/effectivity list.

Source paragraph: 4.3f

Content Model: (term, def)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

appltile

Applicability/Effectivity Definition

Description: Identifies the title for the applicabilty/effectivity list.

Source paragraph: 4.3f

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

apprland

Approach and Landing

Description: Part 8 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.8

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

asymloads

Flight with Assymmetric Loads

Description: Area of Section VI, Flight Characteristics.

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.5

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |

| | | | |
|----------|--|-----------------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

authnot

Authority Notice

Description: Identifies the authority notice at the bottom of the title page.

Source paragraph: 4.5.1.15

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

auxfront

Front matter for volumes/parts

Description: Identifies the front matter that appears in second and subsequent volumes, and second and subsequent parts in a volume.

Source paragraph: 4.2.9.1

Content Model: (idinfo, warnpage?, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist | volilluslist)?, (tablelist | vtablelist)?, (foreword | preface | intro), safesum?) +(ftnote)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

basicdate

Basic Date

Description: Part of the List of current abbreviated checklists.

Source paragraph: 7700G paragraph 3.3.2.2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

body

Body

Description: Identifies the portion of the manual where chapters are used, exclusive of front matter and appendices, indexes, etc.

Source paragraph: 3.3

Content Model: (description, normproc, emergproc, misscrew duty, oplimit, fltchar, ad-weather, fmsection*, perfdatapp*) +(ftnote)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|---------|---|
| numcols | 1 2 | | Allows the author to define the page format as one or two columns for this section of the manual. |

brk

Break

Description: This element is used to indicate that a column, line, or page break should be forced at that point. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------|---------|---|
| type | COL LINE NPG | | Allows the author to define what type of break will occur when the brk element is used - column, line, or page. |

caution

Caution

Description: Identifies a CAUTION in the manual.

Source paragraph: 4.3.10

Content Model: (para*) -(randlist | deflist | seqlist | figure | table | foldout | warning | caution | precaut)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

change

Changed Information

Description: Identifies material that has been changed. In order to add material, the type attribute should be set to add, and the change element should surround the added material. In order to delete material where a complete history of all changes to the document are being preserved, the type attribute should be set to delete and the change element should surround the deleted material. If all changes are not being preserved, change the material and surround it with a change element, setting the type attribute to add.

Source paragraph: 4.7.3.9

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(change | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------|------------------|--|
| level | NMTOKEN | #REQUIRED | Defines the change level for the modification. |

| | | |
|----------|--------------------------|--|
| change | ADD DELETE | Defines the type of change - addition or deletion of text. |
| mark | %YESORNO; 1 | Allows the author to define if a change mark will appear for this change. 1. will produce a change bar on the page - 0 will suppress it. |
| revchg | %YESORNO; 0 | Allows the author to tag whether this modification is for a revision or a change. Zero indicates a change. 1. for a revision. |
| security | (U C S N) N | Identifies security level of the document |

chapter

Chapter

Description: Identifies a chapter.

Source paragraph: 4.2.9.3

Content Model: (title, ((section, section+) | para0+)) +(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

chartlist

Performance Data Chart List

Description: List of Charts for each part of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10.1.1.2, 3.4.10.1.2.2, 3.4.10.1.3.2, etc.

Content Model: ((ptitle)*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| autobuild | CDATA | #CONREF | |
| address | CDATA | #IMPLIED | |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |

checklists

Flight Crew Checklists

Description: Used in the status page to list checklists affected by a change.

Source paragraph: 7700G paragraph 3.2.8, 3.2.8.1 and figure 2.

Content Model: ((tonum, date, tochgnum, tochgdate)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|-------------|
| label | CDATA | #IMPLIED | |

chgdate

Change Date

Description: Identifies the date of the latest change.

Source paragraph: 4.5.1.17

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chghistory

Change History

Description: Identifies the beginning of the change history dates. The first date in the chghist is the original date and subsequent dates are change 1, change 2, etc.

Source paragraph: 4.5.3

Content Model: (chginfo*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chginfo

Change Information

Description: Container element to identify the change information contained in the change history of the document.

Source paragraph: 4.5.3

Content Model: (chgtxt?, date)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chginsst

Change Instruction Sheet

Description: Identifies the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: (chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chglist

Change List

Description: Identifies the Remove Pages and Insert Pages columns on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: (tabmat | (removepg, insertpg)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chgpara

Change para

Description: Identifies the paragraph change status.

Source paragraph: 4.7.3.11.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chgnum

Change Number/Letter

Description: Identifies the latest change number/letter.

Source paragraph: 4.7.3.1, 4.2.1.4.2.3, 4.5.1.17, & 4.5.3.1

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chgrec

Change Record

Description: Identifies the change record page. This page will be an empty table whose contents will be completed by the person filing the change pages in the manual. The change record page will be automatically generated by the FOSI.

Source paragraph: 4.5.5

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chgtxt

Change Text

Description: This element is optional and is used to provide a alpha representation of the current change level. This element will only be tagged by those branches of the armed services that require alpha change numbers. For all other users, this element is optional and should not be tagged.

Source paragraph: 4.5.3

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

chklisttitle

Abbreviated Checklist Title

Description: Part of the List of current abbreviated flight crew checklists.

Source paragraph: 7700G paragraph 3.3.2.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

climb

Climb

Description: Part 4 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.4.

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

clink

Contextual Link

Description: One of several HyTime elements. Can be used in any situation similar to the xref or extref element - will reference any nameloc declared.

Source paragraph:

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| linkend | CDATA | #IMPLIED | References a linkend declared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implemented. |

| | | | |
|----------|-------------------------|-----------------------------------|---|
| HyBase | NAME #FIXED | HYLINK | Used in combination with HyTime to establish contextual link. |
| HyBnames | CDATA #FIXED | REFSUB LINKEND | Used in combination with HyTime to establish contextual link. |
| anchrole | CDATA #FIXED | REFMARK REF- SUB #LIST | Used in combination with HyTime to establish an anchor role for contextual links. |
| anchcstr | NAMES | SELF REQUIRED | Used in combination with HyTime to establish type of anchor string defined for a contextual link. |

clitem

Checklist Item

Description: Checklist step text.

Source paragraph: None. Developed for FOSI use.

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+
+(amplification))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

clstep1

Checklist step 1

Description: Used to differentiate between a plain step and a checklist step.

Source paragraph: None. Developed for FOSI code.

Content Model: ((clitem | condition?)+, clstep2*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |

| | | | |
|-----------|--|----------|--|
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcf | NUMBER | 0 | Fracture Critical Process |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. A **OCP** symbol will appear when set equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. A **OCI** symbol will appear when set equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |
| stepenum | NUMBER | #IMPLIED | |

clstep2

Checklist Step 2

Description: Substep under clstep 1.

Source paragraph: None. Developed for FOSI code.

Content Model: ((clitem | condition?)+, clstep3*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------|----------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |

| | | | |
|-----------|--|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcf | NUMBER | 0 | Fracture Critical Process |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. A **OCP** symbol will appear when set equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. A **OCI** symbol will appear when set equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |
| stepenum | NUMBER | #IMPLIED | |

clstep3

Checklist step 3

Description: Substep under clstep 2

Source paragraph: None. Developed for FOSI code.

Content Model: (clitem)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------|----------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |

| | | | |
|-----------|--|----------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcg | NUMBER | 0 | Fracture Critical Process |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. A **OCP** symbol will appear when set equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. A **OCI** symbol will appear when set equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |
| stepenum | NUMBER | #IMPLIED | |

clstep4

Checklist step 4

Description: Substep under clstep3.

Source paragraph: None. Developed for FOSI code.

Content Model: clitem

clstep3

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------|----------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |

| | | | |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. A **OCP** symbol will appear when set equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. A **OCI** symbol will appear when set equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |
| stepenum | NUMBER | #IMPLIED | |

cmb1

Crew Member 1

Description: Identifies the Crew Member assigned to column 1 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (procstep, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

cmbr2

Crew Member 2

Description: Identifies the Crew Member assigned to column 2 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (procstep, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

cmbr3

Crew Member 3

Description: Identifies the Crew Member assigned to column 3 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (procstep, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

cmbr4

Crew Member 4

Description: Identifies the Crew Member assigned to column 4 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (procstep, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

cubr5

Crew Member 5

Description: Identifies the Crew Member assigned to column 5 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (procstep, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

cogact

Cognizant Field Activity

Description: Identifies Cognizant Field Activity on the title page and is included in the distribution statement. This is a Navy requirement.

Source paragraph: 4.5.1.11

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

colspec

Column Specification

Description: Defines a column in a table. Each column must have a column specification. The column specification defines the width of the column and an optional name used when column is starting or ending a horizontal span or referenced in a table entry. Column specifications in a table group apply to the table heading (boxheads) and the table body. The table heading can redefine the column specifications if needed, however, the table body must use the column specifications defined in the table group.

Source paragraph: 4.3.9

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------|-----------------|--|
| colname | NMTOKEN | #IMPLIED | Allows the author to define a column name. |
| colnum | NUMBER | #IMPLIED | Allows the author to define a column number. |

| | | | |
|----------|--|----------|--|
| align | LEFT RIGHT CENTER JUSTIFY CHAR | | Allows the author to align text within the cell. |
| charoff | NUTOKEN | #IMPLIED | Determines the distance the cell content should offset from the horizontal alignment character. |
| char | CDATA | #IMPLIED | Defines the alignment character that can be used to align values within a column. |
| leftmar | NUTOKEN | #IMPLIED | Defines the left margin for the cell. |
| rightmar | NUTOKEN | #IMPLIED | Defines the right margin for the cell. |
| topmar | NUTOKEN | #IMPLIED | Defines the top margin for the cell. |
| botmar | NUTOKEN | #IMPLIED | Defines the bottom margin for the cell. |
| mindepth | NUTOKEN | #IMPLIED | Allows you to define a minimum depth if desired. |
| colwidth | CDATA | #IMPLIED | Allows you to define the column widths. |
| colsep | %YESORNO; | #IMPLIED | Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators. |
| rowsep | %YESORNO; | #IMPLIED | Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators. |

condition

Condition

Description: Used to state a condition to which a set of steps or paragraphs apply.

Source paragraph: None. Developed for FOSI code.

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |
| security | (U C S N) N | | Identifies security level of the document |

contents

Table of Contents

Description: Identifies the table of contents. For Army documents, the table of contents consists of chapter and section titles. For all other services, the table of contents consists of chapter, section, and paragraph titles. If an index is used, the table of contents consists of chapter, section, and primary paragraph titles. This information is automatically compiled by the FOSI.

Source paragraph: 4.5.6

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |
| security | (U C S N) N | | Identifies security level of the document |

contractno

Contract Number

Description: Identifies the contract number on the title page.

Source paragraph: 4.5.1.4

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

copyright

Copyright Notice

Description: Identifies the copyright notice on the title page.

Source paragraph: 4.1.2 & 4.5.1.14

Content Model: PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

coordprocs

Coordinated Procedures

Description: Provides a means of developing coordinated or simultaneous actions in parallel columns among crew members

Source paragraph: 3.2.12.3

Content Model: (heading, tasks+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|-----------------|---|
| label | CDATA | #IMPLIED | Allows you to label this manually. |
| numcols | 1 2 3 4 5 | | Allows the author to define the number of columns for the Coordinated Procedures. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

crewpos1

Crew Position 1

Description: Defines the first crew position in the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

crewpos2

Crew Position 2

Description: Defines the second crew position in the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

crewpos3

Crew Position 3

Description: Defines the third crew position in the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

crewpos4

Crew Position 4

Description: Defines the fourth crew position in the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

crewpos5

Crew Position 5

Description: Defines the fifth crew position in the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

cruise

Cruise

Description: Part 5 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.5

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

currlists

List of Current Abbreviated Checklists

Description: Listing of current checklists found at the end of the LEP.

Source paragraph: 7700G paragraph 3.3.2.2

Content Model: currlisttbl

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

currlisttbl

List of Current Abbreviated Checklists

Description: List that includes the basic or revision date, change number and date and checklist title. Appears at the end of the LEP.

Source paragraph: 7700G paragraph 3.3.2.2

Content Model: (((basicdate | revisdate), tochgnum, tochgdate, chklisttitle)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|-------------|
| label | CDATA | #IMPLIED | |

dataiden

Data Identification

Description: May be used to identify specific types of data (e.g. hazardous materials, special tools, etc.). Use of this element does not affect the formatted output, but is intended to be used in database functions and data searches.

Source paragraph: 4.5.1.7, 4.5.1.16, 4.5.1.17, & 4.5.3.1

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) - (dataiden | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|------------------|--|
| security | (U C S N) N | | Identifies security level of the element. |
| type | CDATA | #REQUIRED | Defines the type of data being used in the database functions and database searches. |

date

Date

Description: Identifies a date.

Source paragraph: 4.5.1.17 & 4.5.9.4b

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | footnote)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

dateinc

Date Incorporated

Description: Identifies the date the information affected by the directive or engineering change proposal was incorporated into the manual.

Source paragraph: 4.5.9.4d

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

ddchapter

Difference Data Chapter

Description: Identifies the difference data chapter.

Source paragraph: 4.7.3.3

Content Model: (dddesc, (ddindex, ddsheet+)?)+(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |

| | | | |
|----------|--|-----------------|--|
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

dddesc

Difference Data Description

Description: Identifies the lead-in information for the difference data chapter.

Source paragraph: 4.7.3.3

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-
paral*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |

| | | | |
|-----------|--|-----------------|--|
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

ddindex

Difference Data Index

Description: Identifies the paragraph used to lead-in to the difference data index, and its associated list.

Source paragraph: 4.7.3.3.1

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*, ddlist)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |

| | | | |
|-----------|--|-----------------|--|
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

ddlist

Difference Data List

Description: Identifies the listing of part numbers to corresponding difference data sheets.

Source paragraph: 4.7.3.3

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

ddsheets

Difference Data Sheet

Description: Identifies a difference data sheet.

Source paragraph: 4.7.3.3

Content Model: ((nomen, (partno+ | modelno+ | typedes+)), para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

def

Definition

Description: Identifies a term and definition in a list.

Source paragraph: 4.3.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

defhd

Definition List Column Headings

Description: Identifies the column headings for a definition list.

Source paragraph: 4.3.4

Content Model: (term, def)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

deflist

Definition List

Description: Identifies a two-column definition list. This element can be used when a listing is needed to define particular terms.

Source paragraph: 4.3.4

Content Model: (title?, defhd?, (term, def)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|--|-----------------|--|
| rtermwidth | NUTOKEN | 1.9IN | Allows you to set the right term width. |
| ltermwidth | NUTOKEN | 0.7IN | Allows you to define the left term width. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

depart

Departures

Description: Area of Section VI, Flight Characteristics.

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.8

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|------------------------|----------|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

descent

Descent

Description: Part 7 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.7

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

description

Description and Operation

Description: Section I of the basic flight manual.

Source paragraph: 7700G paragraph 3.3.3

Content Model: ((title), secttoc, para0+) +(table | figure | sectocstr | objmedia)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

destr

Destruction Notice

Description: Identifies the destruction notice on the title page.

Source paragraph: 4.5.1.13

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

discl

Disclosure Notice

Description: Identifies the disclosure notice on the title page. The title is automatically generated by the FOSI.
Source paragraph: 4.5.1.10
Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| disclos1 | CDATA | #IMPLIED | Identifies which type of disclosure statement will appear on the title page. Use of this attribute will generate an alternate disclosure notice as opposed the notice generated by the FOSI. |

distrib

Distribution Statement

Description: Identifies the distribution statement. The title is automatically generated by the FOSI.
Source paragraph: 4.5.1.11
Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------------------|---------|--|
| type | A OTHER | | Displays distribution statement A when type is equal to A. Attribute defaults to other allowing the author to enter their own distribution statement text. |

divercvry

Dive Recovery Characteristics

Description: Area of Section VI, Flight Characteristics
Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.4
Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |

| | | | |
|-----------|--|-----------------|--|
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

doc

Document

Description: Identifies the entire document (technical manual).

Source paragraph: 4.1.7

Content Model: (docfm | docfmsupp) +(pgbrk | brk | subjinfo | line | modreq | location)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|---|------------------|--|
| service | (AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD) | #REQUIRED | Identifies which branch of service. |
| docid | CDATA | #IMPLIED | Allows for the author to define an identification number for the document. |
| docstat | (REVISION CHANGE PRELIM DRAFT FORMAL) | PRELIM | Author can stipulate what form the manual is in. |
| verstatpg | (VER UN-VER) | VER | Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail. |
| Index | NUMBER | 0 | Indicated whether an index is included in the manual. Attribute should be set to 1 when an index is present. Use of this attribute will affect the level of detail in the TOC |
| security | (U C S N) | N | Identifies security level of the document |
| controlno | CDATA | 00000000 | System generated attribute values used included for compliance with the JCALS menu structure. |
| cycle | CDATA | NEW | System generated attribute values used included for compliance with the JCALS menu structure. |
| chglevel | NUMBER | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| initlabel | NUMBER | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| initpage | NUMBER | 1. | System generated attribute values used included for compliance with the JCALS menu structure. |
| docno | CDATA | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| highguid | NUMBER | 0 | System generated attribute values used included for compliance with the JCALS menu structure. |
| labelstyle | CDATA | FAN | System generated attribute values used included for compliance with the JCALS menu structure. |
| HyTime | NAME #FIXED | HYDOC | Used to alert the processing system that this is a HyTime compliant document. This attribute is only required and/or effective with a HyTime aware processor. |

docfm

Flight Manual

Description: Basic flight manual document.
Source paragraph: 7700G paragraph 3.3
Content Model: (front, body, rear) +(pgbrk | brk | ftnote)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-------------|----------------|------------------|---|
| paranumbers | (0 1) | #REQUIRED | |
| controlno | CDATA | 00000000 | System generated attribute values used included for compliance with the JCALS menu structure. |
| cycle | CDATA | NEW | System generated attribute values used included for compliance with the JCALS menu structure. |
| chglevel | NUMBER | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| initlabel | NUMBER | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| initpage | NUMBER | 1 | System generated attribute values used included for compliance with the JCALS menu structure. |
| docno | CDATA | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| highguid | NUMBER | 0 | System generated attribute values used included for compliance with the JCALS menu structure. |
| labelstyle | CDATA | FAN | System generated attribute values used included for compliance with the JCALS menu structure. |

docfmsupp

Flight Manual Supplements

Description: Operational and Safety Supplements to the basic flight manual.
Source paragraph: 7700G paragraph 3.2.7
Content Model: safsupp?, opsupp?

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| controlno | CDATA | 00000000 | System generated attribute values used included for compliance with the JCALS menu structure. |
| cycle | CDATA | NEW | System generated attribute values used included for compliance with the JCALS menu structure. |
| chglevel | NUMBER | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |

| | | | |
|------------|--------|----------|---|
| initlabel | NUMBER | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| initpage | NUMBER | 1 | System generated attribute values used included for compliance with the JCALS menu structure. |
| docno | CDATA | #IMPLIED | System generated attribute values used included for compliance with the JCALS menu structure. |
| highguid | NUMBER | 0 | System generated attribute values used included for compliance with the JCALS menu structure. |
| labelstyle | CDATA | FAN | System generated attribute values used included for compliance with the JCALS menu structure. |

docpart

(Document) Part

Description: Identifies the next breakdown of a volume.

Source paragraph: 4.5.1

Content Model: ((front | auxfront), body, rear?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|----------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| security | (U C S N) N | | Identifies security level of the document |

docpartn

(Document) Part Number

Description: Specifies the number used to identify a (document) part

Source paragraph: NONE

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

doctype

Type of Manual

Description: Identifies the type of manual on the title page (e.g. maintenance instructions, illustrated parts breakdown, inspection manual, etc.).

Source paragraph: 4.1.7

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

downgrd

Downgrade Notice

Description: Identifies the classification downgrade notice on the title page.

Source paragraph: 4.4

Content Model: (phrase | oadr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

ecpno

Engineering Change Proposal Number

Description: Identifies the ECP Number in the record of applicable technical directives.

Source paragraph: 4.5.9.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

effdatenot

Effective Date Notice

Description: Identifies the effective date notice on the title page.

Source paragraph: 4.5.1.8

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

emergproc

Emergency Procedures

Description: Section III of the basic flight manual.

Source paragraph: 7700G paragraph 3.3.5

Content Model: ((title), secttoc, (phaseops | system)) +(figure | table | objmedia |
sectocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |

| | | | |
|----------|--|----------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

emerprocnot

Emergency Procedures Notice

Description: Canned statement that appears on classified flight manuals.

Source paragraph: 7700G paragraph 3.3.2.1.3

Content Model: notice+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

emphasis

Emphasis

Description: Identifies portions of text to be highlighted (e.g. underline, bold, etc.). This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) - (emphasis | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------|--|
| type | (U B BU I BI Q X O SUP SUB UI) | #REQUIRED | Displays different types of emphasis. u=underline b=bold bu=bold/underline i=italics bi=bold/italics q=quotes x=box o=overscore sup=superscript sub=subscript ui=underline/italics |

| | | | |
|---------|---|-----------------|--|
| fonsize | NUTOKEN | #IMPLIED | Allows author to set the font size which will be applied to the text within the emphasis tags. |
| color | BLACK WHITE RED ORANGE YELLOW GREEN BLUE VI- OLET BROWN GRAY | #IMPLIED | Specifies the color of the text. |

end

End

Description: Puts an "END" label

Source paragraph:

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

endure

Endurance

Description: Part 6 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.6

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |

| | | | |
|----------|--|----------|--|
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

engdata

Engine Data

Description: Part 2 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.2

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|----------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

| | | |
|----------|-------------------|---|
| security | (U C S N) N | Identifies security level of the element. |
|----------|-------------------|---|

engineops

Engine Operation

Description: Area of Section VI, Flight Characteristics

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.10

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |

| | | | |
|----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

entry

Table Entry

Description: Identifies a table entry (cell).

Source paragraph: 4.2.7

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | randlist | deflist | seqlist | warning | caution | note)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-----------------------------------|-----------------|--|
| colname | NMTOKEN | #IMPLIED | Allows you to identify a name for each column. |
| spanname | NMTOKEN | #IMPLIED | Allows you to identify a name for each span. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| morerows | NUMBER | 0 | Allows you to define a vertical span on entries within a table. |
| colsep | %YESORNO; | #IMPLIED | Toggle switch to determine if column separators appear in a table. Colsep=1 means column separators will appear. |
| rowsep | %YESORNO; | #IMPLIED | Toggle switch to determine if row separators appear in a table. rowsep=1 means column separators will appear. |
| rotate | %YESORNO; | 0 | Toggle switch to rotate the contents of the entry 90 degrees. |
| valign | (TOP MID-DLE BOT-TOM) | #IMPLIED | Defines the vertical alignment of text within a cell. |

| | | | |
|----------|--|----------|---|
| align | (LEFT RIGHT CENTER JUSTIFY CHAR) | #IMPLIED | Defines the horizontal alignment of text within a cell. |
| charoff | NUTOKEN | #IMPLIED | Determines the distance the cell content should offset from the horizontal alignment character. |
| char | CDATA | #IMPLIED | Defines the alignment character that can be used to align values within a column. |
| security | (U C S N) N | | Identifies security level of the document |

entrytbl

Entry Table

Description: Identifies a table within a table entry. This element allows a table cell to be divided into a sub-table, with its own set of rows, columns, and entries. Use of this element basically allows the author to create a table within a table.

Source paragraph: 4.2.7

Content Model: (colspec*, spanspec*, thead?, tbody) -(entrytbl)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------|--|
| cols | NUMBER | #REQUIRED | Allows you to define the number of columns. |
| colname | NMTOKEN | #IMPLIED | Allows you to identify a name for each column. |
| spanname | NMTOKEN | #IMPLIED | Allows you to define a name for each span that is defined for the table. |
| colsep | %YESORNO; | #IMPLIED | Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators. |
| rowsep | %YESORNO; | #IMPLIED | Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators. |
| align | LEFT RIGHT CENTER JUSTIFY CHAR | | Allows the author to align text within the cell. |
| charoff | NUTOKEN | #IMPLIED | Determines the distance the cell content should offset from the horizontal alignment character. |
| char | CDATA | #IMPLIED | Defines the alignment character that can be used to align values within a column. |
| security | (U C S N) N | | Identifies security level of the document |

esds

Electrostatic Discharge Sensitive Symbol

Description: Identifies the ESDS symbol. Use of this element will cause the ESDS symbol to appear at that point in the running text. The esds attribute should be used to place the ESDS symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.4

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

estdistr

Estimated Distribution Date

Description: Found on Status Page for changes.

Source paragraph: 7700G Figure 2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

expcont

Export Control Notice

Description: Identifies the export control notice on the title page. Note that the export control notice entity (&expcontnot;) may be used in place of entering the text manually.

Source paragraph: 4.5.1.12

Content Model: (#PCDATA) + (emphasis)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

extref

External Reference

Description: Generates a reference to an external document.

Source paragraph: 4.3.1m

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|--------------|-------------------------|-----------------------|---|
| targetdoc | CDATA | #IMPLIED | Identifies the external document that you are referencing. This value should equal an ID specified in the List of Related Publications. For implementing external references in digital data - this ID must equal the ID of the external document. |
| targetid | CDATA | #IMPLIED | Provides the ID for the element being referenced in the external document. The value of this attribute should equal the ID of an element in the referenced document. |
| displayvalue | CDATA | #IMPLIED | If the author needs to add additional, unique information for purposes of referencing an external document, this attribute should be tagged. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable. |
| HyTime | NAME #FIXED | CLINK | Used in combination with HyTime to establish contextual link. |
| HyNames | CDATA #FIXED | LINKEND XREFID | Used in combination with HyTime to establish contextual link. |

fc

Fracture Critical Parts

Description: Identifies the fracture critical parts.

Source paragraph: 4.3.8.5

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

figno

Figure Number

Description: Identifies the figure number within the illustration list when the illustration list is manually tagged.

Source paragraph: NONE

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

figtable

Table within a figure

Description: Identifies a table contained within a figure, which does not have a table number or name, and does not appear in the list of tables. An example would be a component table on a schematic diagram.

Source paragraph: 4.3.9.1

Content Model: (tgroup+) -(figure | table | foldout) +(tfoot | tfnref | tfndisplay)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---|----------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| frame | TOP BOT-TOM TOPBOT ALL SIDES NONE | | Defines the frame for the table. |
| colsep | %YESORNO; 1 | | Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators. |
| rowsep | %YESORNO; 0 | | Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators. |
| tbwidth | NUTOKEN | #IMPLIED | |
| tbdepth | NUTOKEN | #IMPLIED | |
| horrefpt | (LEFT RIGHT) | LEFT | Defines the horizontal reference point for the table. |
| verrefpt | (VTOP VBOTTOM) | VTOP | Defines the vertical reference point for the table. |
| coordst | CDATA | 0,10000 | Ability to define the coordinates to start the table. |
| assocfig | IDREF | #IMPLIED | Provides a means to add the id to an associated figure. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

figure

Figure

Description: Identifies an illustration.

Source paragraph: 4.2.8

Content Model: (title, ((subfig, subfig+) | ((graphic, legend?) | figtable)+)) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| pgwide | %YESORNO; 1. | | Defines whether the figure will fill the entire width of the page. |
| orient | (PORT LAND) | PORT | Defines the orientation of the figure. |
| legend | %YESORNO; 0 | | This attribute is set to 1 when a legend is tagged as part of the figure. |
| security | (U C S N) N | | Identifies security level of the document |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |

| | | | |
|-----------|---------------|----------|---|
| emergency | NUMBER | 0 | Allows you to declare a figure an emergency (in the performance data section) and place that figure only on an emergency bordered page. |
|-----------|---------------|----------|---|

fixedwing

Fixed Wing Aircraft

Description: Selection made at perfdattapp element to select fixed wing aircraft for the performance data appendix.

Source paragraph: 7700G paragraph 3.4

Content Model: (pdcontents, introduction, engdata, pdtakeoff, climb, cruise, endure, descent, apprland, msnplan, optionalsection*) +(partocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

fltchar

Flight Characteristics

Description: Section VI of the basic flight manual.

Source paragraph: 7700G paragraph 3.3.8

Content Model: ((title), secttoc, para0*, fltcontrol, normfltchars, divercvry, asymloads, abnormflt, stalls, depart, spins, engineops, para0*) +(figure | table | objmedia | sectocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

fltcontrol

Flight Control System

Description: Area of Section VI, Flight Characteristics.

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.2

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |

| | | | |
|-----------|--|-----------------|--|
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

fmsection

Flight Manual Generic Section

Description: Optional section for including additional information required by the acquiring activity but not required by the spec.

Source paragraph: 7700G paragraph 3.3

Content Model: ((title), secttoc, (para0 | procedure)+) +(figure | table | objmedia | sectocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

foldout

Foldout

Description: Identifies a foldout.

Source paragraph: 4.2.4.1

Content Model: (title, ((subfig, subfig+) | ((graphic, legend?) | figtable)+)) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|---|----------|--|
| pgstyle | 11X17 11X20.5 11X24 11X27.5 11X31 11X34.5 11X38 11X41.5 11X45 | | Defines the pagesize for the foldout. |
| blankapron | %YESORNO; | 1. | Toggle to indicate whether the foldout includes a blank apron. A value of 1. indicates that the foldout will have a blank apron. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| pgwide | %YESORNO; | 1. | Defines whether the figure will fill the entire width of the page. |
| orient | (PORT LAND) | PORT | Defines the orientation of the figure. |
| legend | %YESORNO; | 0 | This attribute is set to 1 when a legend is tagged as part of the figure. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

foldsect

Foldout Section

Description: Identifies the area where foldouts are placed when they are included at the end of the manual. This element is not marked as a chapter or section, but is merely a placeholder for the foldouts.

Source paragraph: 4.2.4.1d

Content Model: (foldout+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

foreword

Foreword

Description: Identifies the foreword of the manual. This element is identical to the preface and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: (para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp)*, tctolist, tmimpres?) +(figure | table)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

front

Front Matter

Description: Identifies the front matter of the manual.

Source paragraph: 4.5

Content Model: (idinfo, warnpage?, chginsst?, lep, (currlists | statuspge)?, verstat?, tpdr?, chgrec?, contents, illuslist?, tablelist?, (foreword | preface | intro), safesum?) +(ftnote)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------|---------|---|
| t2page | %YESORNO; 0 | | A toggle that allows the author to turn the second title page on if necessary. |
| numcols | 1 2 | | Allows the author to define the page format as one or two columns for this section of the manual. |

ftnote

Footnote

Description: Identifies footnotes to paragraphs and tables. The footnote appears on the same page that the corresponding footnote reference (<ftnref>) occurs. Only the footnote whose id matches the xrefid specified in the footnote reference will appear. Footnotes to text will be displayed at the bottom of the page where the footnote is referenced

Source paragraph: 4.3.1n, 4.2.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | randlist | deflist | seqlist)+) -(ftnote | ftnref | figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|------------------|--|
| id | ID | #REQUIRED | This allows you to identify each element and later reference it by its id value. |
| security | (U C S N) N | | Identifies security level of the document |

ftnref

Footnote Reference

Description: Identifies a reference to a footnote. This element will cause the footnote number/letter/symbol to appear at the point in the text where used, and will cause the footnote number/letter/symbol and the footnote text to appear at the bottom of the page.

Source paragraph: 4.3.1n

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|------------------|--|
| xrefid | IDREF | #REQUIRED | Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual. |
| mark | NUM SYM ALPHA | | Indicates the type of symbol or mark used to indicate a footnote. |

genemerg

General Emergency Procedures

Description: Area of Section III, Emergency Procedures. Part of both phase of operations arrangement and system arrangement.

Source paragraph: 7700G paragraph 3.3.5, 3.3.5.1.1, 3.3.5.1.2, and 3.3.5.5

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

glossary

Glossary

Description: Identifies the glossary of the manual.

Source paragraph: 4.2.9.7

Content Model: ((letter?, glosslist)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

glosslist

Glossary List

Description: Container element for the glossary list of definitions and terms.

Source paragraph: NONE

Content Model: (letter?, (term, def))+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

graphic

Graphic

Description: Identifies a graphic within a figure, or a graphic within running text or tables. If used within running text, no figure number or title will be generated. Note that the HCP and ESDS symbols can be placed in running text by using the hcp and esds elements. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------------------------|------------------|---|
| boardno | ENTITY | #REQUIRED | Allows the author to place the graphic name here. |
| graphsty | NMTOKEN | #IMPLIED | Graphic style |
| llcordra | CDATA | #IMPLIED | Lower left world coordinates (1,1). If scalefit=0 and repropid is not specified default is lower left. |
| rucordra | CDATA | #IMPLIED | Upper right world coordinates (10000,10000). If scalefit=0 and reprodep is not specified default is upper right. |
| repropid | NUTOKEN | #IMPLIED | Specifies the horizontal dimension of a graphic bounding box (width). |
| reprodep | NUTOKEN | #IMPLIED | Specifies the vertical dimension of a graphic bounding box (depth). |
| hscale | NUMBER | #IMPLIED | Horizontal Scaling |
| vscale | NUMBER | #IMPLIED | Vertical Scaling |
| scalefit | NUMBER | #IMPLIED | Scale to fit. No affect if hscale and vscale set to zero. |
| color | NUMBER | 0 | Option to choose color. |
| coordst | CDATA | #IMPLIED | Specifies coordinate to start graphic. |
| coordend | CDATA | #IMPLIED | Specifies coordinate to end graphic. |
| icon | (YES NO) | NO | Specifies whether the graphic is full size or icon. Specifying icon will eliminate the textbrk surrounding the graphic. |
| security | (U C S N) | N | Identifies security level of the document |

grndops

Ground Operation Emergency Procedures

Description: Area of Section III, Emergency Procedures.

Source paragraph: 7700G paragraph 3.3.5 and 3.3.5.6

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|--------------------------|----------|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

hazmat

Hazardous Material Name

Description: Identifies the hazardous material name used with a hazardous material warning icon.

Source paragraph: 4.3.10.1

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

hci

Hardness Critical Item

Description: Identifies the HCI symbol. Use of this element will cause the HCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCI symbol in a paragraph. The hci attribute should be used to place the HCI symbol between a paragraph/step number and text.

Source paragraph: 4.3.8.3.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

hcp

Hardness Critical Process Symbol

Description: Identifies the HCP symbol. Use of this element will cause the HCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCP symbol in a paragraph. The hcp attribute should be used to place the HCP symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.3.1

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

heading

Heading

Description: Defines the heading for the Coordinated Procedures table

Source paragraph: 3.2.12.3

Content Model: (crewpos1, crewpos2, crewpos3?, crewpos4?, crewpos5?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

helicopter

Helicopter

Description: Selection made at the performdatapp element to select helicopter performance data appendix.

Source paragraph: 7700G paragraph 3.4 and 3.4.10.10

Content Model: (parttoc, chartlist, (para0 | figure)+) +(partocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

icon

Hazardous Material Warning Icon

Description: Identifies the hazardous material warnings. The hazardous material warning consists of a graphic(s) (e.g fire icon, poison icon, etc.), the hazardous material name, and the sequence number which identifies the order in which the hazardous material warnings are included in the safety summary. See Appendix A for further information on hazardous material warnings.

Source paragraph: 4.3.10.1

Content Model: (graphic+, hazmat, seqno)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-----------|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |

idinfo

Identification Information (Title Page)

Description: Identifies the title page and cover (if used) of the manual.

Source paragraph: 4.5.1

Content Model: (tmidno+, (chgnum, chgdate)?, chghistory, pretmidno*, doctype?, prtitle, subtitle?, graphic?, (mfr, contractno+)?, supersed?, suppl*, emer-procnot?, discl?, distrib, expcont?, destr?, copyright*, moveddata?, authnot, downgrd?, pubdate)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------|-------------|--|
| tmidnolen | NUTOKEN | 10EM | Specifies potential length for the T.M. ID number. |

ilink

Independet Link

Description: One of several HyTime elements. Used in a situation of indirection where a specific ID is not declared in an external document and must be declared using `nameloc` and `nmllist` elements.

Source paragraph:

Content Model: (PCDATA)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|------------------|--|
| linkends | CDATA | #IMPLIED | References the linkends declared within a <code>nameloc</code> element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implemented. |
| anchrole | CDATA | #REQUIRED | Defines the anchor role assumed by the independent link. Used in combination with HyTime. |

illuslist

List of Illustrations

Description: Identifies the list of illustrations in the manual. This information is automatically compiled by the FOSI. If this element is not used, no list of illustrations will appear in the manual.

Source paragraph: 4.5.7

Content Model: (figno, title, pageno)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |
| security | (U C S N) N | | Identifies security level of the document |

index

Index

Description: Identifies the index.

Source paragraph: 4.2.9.8

Content Model: (letter?, (preentry, secentry*))+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |

| | | |
|----------|-------------------|---|
| security | (U C S N) N | Identifies security level of the document |
|----------|-------------------|---|

inflight

In-Flight Emergency Procedures

Description: Area of Emergency Procedures. Part of the phase of operations arrangement.

Source paragraph: 7700G paragraph 3.3.5, 3.3.5.1.1, and 3.3.5.8

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |

| | | | |
|----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

insertpg

Insert Page Column Entry

Description: Identifies an entry within the Insert Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

internatlst

International Standardization Agreement Note

Description: Identifies the international standardization agreement note. The paragraph number and title, of this note will be automatically generated by the FOSI.

Source paragraph: 4.5.9.1

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|-----------------|--|
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

intro

Introduction

Description: Identifies the introduction of the manual. This element is identical to the preface and foreword elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: (para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp)*, tctolist, tmimpres?) +(figure | table)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

introduction

Introduction

Description: Part 1 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.1

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| | | | |

| | | | |
|----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

intropara

Introductory Paragraph

Description: Area of Section III, Emergency Procedures. Part of both phase of operations arrangement and system arrangement.

Source paragraph: 7700G paragraph 3.3.5.1.1 and 3.3.5.1.2

Content Model: (para0)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |

| | | | |
|-----------|-------------------------------------|----------|--|
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

item

Item

Description: Identifies an item within a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|-----------------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| security | (U C S N) N | | Identifies security level of the document |

landing

Landing Emergency Procedures

Description: Area of Section III, Emergency Procedures. Part of phase of operations arrangement.

Source paragraph: 7700G paragraph 3.3.5.1.1 and 3.3.5.9

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |

| | | | |
|-----------|--|-----------------|--|
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

legend

Legend

Description: A tabular listing of the index numbers/letters and their meanings.

Source paragraph: 4.6.17

Content Model: tabmat

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

lep

List of Effective Pages (LEP)

Description: Identifies the list of effective pages for the manual.

Source paragraph: 4.5.3
Content Model: lepcontents

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

lepcontents

LEP Contents

Description: Contains the entries for the lep. The fosi automatically can generate this.
Source paragraph: 4.5.3
Content Model: (lepentry+)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |

lepentry

LEP Entry

Description:
Source paragraph: 4.5.3
Content Model: leppage, lepchg

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

lepchg

LEP Change

Description:
Source paragraph: 4.5.3.1
Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

leppage

LEP Page

Description:

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

letter

Leter

Description: Letter heading for the index.

Source paragraph: 4.2.9.8

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

line

Line

Description: This element is used to indicate that a column or line should be forced at that point.

Source paragraph: N/A

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|-----------------|--|
| prespace | CDATA | #IMPLIED | Allows the authour to set amount of space before/above the line used. |
| postspace | CDATA | #IMPLIED | Allows the authour to set amount of space before/above the line used |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| quad | LEFT CENTER RIGHT JUSTIFY | LEFT | Specifies quadding option for the line. |
| indent | CDATA | #IMPLIED | Specifies how much indentation is set on the line. |

location

Location (Not Used; Under Review)

Description: Identifies the placement of a floating object such as a figure, table or figure table. This element is globally included on the document element.

Source paragraph: N/A

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| xrefid | IDREF | #IMPLIED | Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual. |

Irp

List of Related Publications

Description: Identifies the paragraph used to list related publications and the associated list.

Source paragraph: 4.5.9.2

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*, lrptable?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|-------------------------------------|-----------------|---|
| ltermwidth | NUTOKEN | 1.63IN | Allows you to define the left term width. |
| rtermwidth | NUTOKEN | 1.9IN | Allows you to set the right term width. |
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

Irpretry

List of Related Publications Entry

Description: Identifies an entry in the list of related publications. When the value of the id attribute is specified via the xrefid attribute of the extref element, the title of the publication appears.

Source paragraph: 4.5.9.2

Content Model: ((partno | (modelno | typedes))* , tmidno+ , title)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-----------|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |

maintlvl

Maintenance Level

Description: Identifies the maintenance level of the manual (e.g. organizational, intermediate, depot, etc.) on the title page.

Source paragraph: 4.5.1.3.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

Irptable

List of Related Publications Table

Description: Container element for the list of related publications table.

Source paragraph: 4.5.9.2

Content Model: lrpretry+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

mfr

Manufacturer

Description: Identifies the manufacturer of the equipment on the title page.

Source paragraph: 4.5.1.3.6

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

miscemerg

Miscellaneous Emergency Procedures

Description: Area of Section III, Emergency Procedures. Part of both phase of operations arrangement and system arrangement.

Source paragraph: 7700G paragraph 3.3.5.1.1, 3.3.5.1.2, and 3.3.5.11

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |

| | | | |
|----------|--|-----------------|--|
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

misscrewduity

Mission Crew Duties/Procedures

Description: Section IV of the basic flight manual

Source paragraph: 7700G paragraph 3.3.6

Content Model: ((title), seeto?, (secttoc, para0+)*)+(figure | table | objmedia | sectocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |
| appears | YES NOTAPPLIC SEPMAN | | |

modelno

Model Number

Description: Identifies the model number of the equipment on the title page or difference data sheet.

Source paragraph:

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

modreq

Modification Request (Not Used; Under Review)

Description: The modification request element identifies a marking which document editors may place into the document instance to indicate where modification should be made. The element is used only in the review process and will not be used during document composition.

Source paragraph: 4.5.1.3.4, 4.7.3.3

Content Model: mrinfo?, mrmod, mrrespns?

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------------------------------------|------------------|---|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| xref | NMTOKEN | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| refpos | (PREXREF POSTXREF XREF) | XREF | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| by | CDATA | #REQUIRED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| date | CDATA | #REQUIRED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| organiz | NMTOKEN | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| orgcat | NMTOKEN | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |

| | | | |
|----------|----------------------------|-----------------|---|
| cmntrcat | NMTOKEN | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| priority | (1 2 3 4 5) | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| category | NMTOKEN | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| topic | CDATA | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |

movedata

Moved Data

Description: Provides a means to identify the type of information that will appear on the T-2 page when the title page overflows.

Source paragraph: NONE

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrchgtxt

Modification Request Change Text (Not Used; Under Review)

Description: Identifies the modification request change text used to indicate editorial changes during document production. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: ANY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| chgloc | NUMBER | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
| chglen | NUMBER | #IMPLIED | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |

| | | | |
|--------|--|----------------|---|
| action | INSERT DELETE REPLACE | REPLACE | Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review. |
|--------|--|----------------|---|

mrngenmod

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrinfo

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: ANY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrinstr

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mritem

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrlist

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mritem+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrmod

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrreason?, (mrgenmod | (mrinstr?, mrchgtxt)))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrpara

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrreason

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

mrrespns

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: (mrpara | mrlist)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------|-----------------|--|
| disposn | NMTOKEN | #IMPLIED | Attribute currently not supported by the FOSI. The element and attribute are under review. |
| status | NMTOKEN | #IMPLIED | Attribute currently not supported by the FOSI. The element and attribute are under review. |

msnplan

Mission Planning

Description: Part 9 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.9

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

nameloc

Name Location - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a locator for external references and contains several nmlist elements. Useful for referencing objects that do not have the traditional SGML id.

Source paragraph:

Content Model: (nmlist)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------------------------|-----------------|--|
| HyBase | NAME #FIXED | NAMELOC | Assigns nameloc as the HyBase attribute. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |

newpage

New Page

Description: Forces a new page in safety or operational supplements.

Source paragraph: None.

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

newpos1

New Position 1

Description: Identifies the new crew position for column 1 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

newpos2

New Position 2

Description: Identifies the new crew position for column 2 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

newpos3

New Position 3

Description: Identifies the new crew position for column 3 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

newpos4

New Position 4

Description: Identifies the new crew position for column 4 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

newpos5

New Position 5

Description: Identifies the new crew position for column 5 of the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

nmlist

Name List - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a description of the location of the entity or element reference in the nameloc element. Useful for referncing objects that do not have the traditional SGML id and/or entities that reside in external documents.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-----------------------------|--|---|
| nametype | (ENTITY ELEMENT) | ENTITY | Identifies whether the external reference is an element or entity. |
| docorsub | ENTITY | #IMPLIED | Defines the entity name of the external document as declared in the entity declarations at the top of the tagged instance. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement. |
| HyBase | NAME #FIXED | NMSPLOC | Used in conjunction with HyTime to set up independent and contextual links. |
| impsrc | NAME #FIXED | GROVERT | Used in conjunction with HyTime to set up independent and contextual links. |
| HyBnames | CDATA #FIXED | LOCSRC DOCOR-SUBNAMESPC NAMETYPE#MAPTOKEN ELEMENTS ELEMENT#MAPTOKEN ENTITIES ENTITY | Used in conjunction with HyTime to set up independent and contextual links. |
| notspace | NAME | ERROR | Used in conjunction with HyTime to set up independent and contextual links. |
| notname | NAME | ERROR | Used in conjunction with HyTime to set up independent and contextual links. |
| notprop | NAME | ERROR | Used in conjunction with HyTime to set up independent and contextual links. |
| direct | (DIRECT IN-DIRECT) | INDIRECT | Used in conjunction with HyTime to set up independent and contextual links. |
| locsrc | CDATA | #IMPLIED | Used in conjunction with HyTime to set up independent and contextual links. |
| cantcnst | NAME | ERROR | Used in conjunction with HyTime to set up independent and contextual links. |

nomen

Nomenclature

Description: Identifies the nomenclature of the equipment on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

none

None

Description: Allows you to opt for none instead of having the tpdrtbl.

Source paragraph:

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

normfltchars

Normal Flight Characteristics

Description: Area of Section VI, Flight Characteristics.

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.3

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |

| | | | |
|-----------|--|-----------------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

normproc

Normal Procedures

Description: Section II of the basic flight manual.

Source paragraph: 7700G paragraph 3.3.4

Content Model: ((title), secttoc, (para0 | procedure)+) +(table | figure | sectocstr | objmedia)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

notapplic

Not Applicable

Description: Used when the Mission Crew Duties section of the flight manual is not used to output "not applicable" on the section title page.

Source paragraph: 7700G paragraph 3.3.6

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

note

Note

Description: Identifies a NOTE in the manual.

Source paragraph: 4.3.10

Content Model: (para*) -(randlist | deflist | seqlist | figure | table | foldout | precaut | warning | caution)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

notice

Notice

Description: Notice paragraphs found in Emergency Procedures Notice for classified flight manuals.

Source paragraph: None. Developed for FOSI code.

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

n_{sn}

National Stock Number

Description: Identifies the national stock number of the equipment on the title page.

Source paragraph: 4.5.1.3.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

n_{sp}

Description: Identifies the n_{sp} symbol. Use of this element will cause the n_{sp} symbol to appear at that point in the running text. The n_{sp} attribute should be used to place the n_{sp} symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.21

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

o_{adr}

Official Authority Downgrade Review Notice

Description: Identifies the official authority downgrade review notice on the title page. This notice is used only on classified manuals.

Source paragraph: 4.4 & 4.5.1.10

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

object

Multimedia Object

Description: Developed for use in interactive manuals to evoke multimedia applications.

Source paragraph:

Content Model: (param)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|------------------|--|
| objectno | ENTITY | #REQUIRED | References the object number of the application being referenced. |
| reprowid | NUTOKEN | #IMPLIED | Provides width of object being invoked, especially if graphic or foldout from external document. |
| reprodep | NUTOKEN | #IMPLIED | Provides depth of object being invoked, especially if graphic or foldout from external document. |
| type | CDATA | #IMPLIED | Provides details about the type of applications being referenced. |
| security | (U C S N) N | | Identifies security level of the document |

objmedia

Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph:

Content Model: (title, ((subobjmed, subobjmed+) | object)) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |

| | | | |
|----------|--|----------|--|
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

oci

Observable Critical Item

Description: Identifies the OCI symbol. Use of this element will cause the OCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the OCI symbol in a paragraph. The oci attribute should be used to place the OCI symbol between a paragraph/step number and text.

Source paragraph: 4.3.8.6.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

ocp

Observable Critical Process

Description: Identifies the OCP symbol. Use of this element will cause the OCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the OCP symbol in a paragraph. The ocp attribute should be used to place the OCP symbol between a paragraph/step number and text.

Source paragraph: 4.3.8.6.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

oplimit

Operating Limits

Description: Section V of the basic flight manual.

Source paragraph: 7700G paragraph 3.3.7

Content Model: ((title), secttoc, para0+) +(figure | table | foldout | objmedia, sectocstr)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|------------------------|----------|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

opsupp

Operational Supplement

Description: Selection made at the docfmsupp element level.

Source paragraph: 7700G paragraph 3.2.7

Content Model: (suppfront, suppbody)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

optionalsection

Optional Section

Description: Repeatable optional section of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4

Content Model: (title, parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

nameloc

Name Location - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a locator for external references and contains several nmlist elements. Useful for referncing objects that do not have the traditional SGML id.

Source paragraph:

Content Model: (nmlist)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------|-----------------|--|
| HyBase | NAME #FIXED | NAMELOC | Assigns nameloc as the HyBase attribute. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |

page

Page Number

Description: Tag generated by OmniMark when building the section TOCs and part TOCs.

Source paragraph: None.

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

pageno

Page Number

Description: Identifies the page number associated with each table/figure that appears in the tablelist or illuslist when the list is manually tagged.

Source paragraph: NONE
Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the *fosi*.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

para

Paragraph

Description: Identifies text within a paragraph without regard to title, heading, etc. For example, a NOTE consists of a heading and one or more paragraphs.

Source paragraph: 4.2.9.5

Content Model: (((#PCDATA | change | tabmat | ftref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | randlist | deflist | seqlist)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the *fosi*.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| xrefid | IDREF | #IMPLIED | Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

para0

Primary Paragraph

Description: Identifies a primary paragraph within the manual.

Source paragraph: 4.2.9.5.1.1

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-
paral*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

param

Parameter

Description: Used with Object Media to provide textual information about the application being invoked.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

paratitle

Paragraph Title

Description: Identifies the paragraph title.

Source paragraph: 4.3e

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

partno

Part Number

Description: Identifies the part number of the equipment on the title page and on the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1b

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

partocstr

Part Table of Contents string

Description: Tag used to for "a single entry designating the general subject matter" of closely related primary paragraphs. Used by OmniMark to create the part table of contents for each part of the performance data appendix.

Source paragraph: 7700G paragraph 3.3.2.4

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

parttoc

Table of Contents for Performance Data

Description: Autogenerated TOC for each part of the performance data appendix. Created by OmniMark program.

Source paragraph: 7700G paragraph 3.4.1

Content Model: ((ptitle)*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| autobuild | CDATA | #CONREF | |
| address | CDATA | #IMPLIED | |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |

pdcontents

Performance Data Table of Contents

Description: Table of contents that lists parts 1 through 9 of the performance data appendix.

Source paragraph: 7700G paragraph 3.4.1

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|-----------------|---|
| autobuild | CDATA | #CONREF | |
| address | CDATA | #IMPLIED | |
| security | (U C S N) N | | Identifies security level of the document |

pdtakeoff

Takeoff

Description: Part 3 of the Performance Data appendix.

Source paragraph: 7700G paragraph 3.4.10 and 3.4.10.3

Content Model: (parttoc, chartlist, para0+, figure+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

perfdatapp

Performance Data Appendix

Description: When specified, the associated performance data shall be provided as an appendix within the flight manual.

Source paragraph: 7700G paragraph 3.3 and 3.4

Content Model: ((title), (fixedwing | helicopter))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |
| numcols | 1 2 | | |

pgbrk

Page Break

Description: Identifies where a page will begin. Page breaks can be placed at the top of each logical page to identify where the page should start.

Source paragraph: 4.2.1.1

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|---------------|--|-----------------|---|
| pgnum | CDATA | #IMPLIED | Page number generated by the FOSI during a recomposition. Provides data for OmniMark and DataLogics Composer in the script and change package processing. |
| pgnumber | CDATA | #IMPLIED | Allows the author to assign the pgnumber. |
| pgdesc | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| nxtpgnum | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| nxtpgdesc | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| seqnum | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| prefix | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| rectover | NUMBER | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| empty | NUMBER | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| ignore | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| chgstatus | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| prevchgstatus | CDATA | #IMPLIED | Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process. |
| chglevel | NMTOKEN | #IMPLIED | Specifies what level of change the manual is on. |
| emergency | (0 1) | #IMPLIED | If emergency is equal to 1, it will output the emergency border to signify emergency procedures. |
| shrink | CDATA | #IMPLIED | Used to shrink vertical space so that overflowed text will pull back to the desired page. |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| hyphflag | NUMBER | #IMPLIED | Toggle whether or not hyphen will be used for the last word on the last line. |
| paraflag | NUMBER | #IMPLIED | Toggle whether or not last para will split. |
| security | (U C S N) N | | Identifies security level of the document |

pgnumber

Page Number

Description: Identifies the page number.

Source paragraph: 4.2.1.4.2.1

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

phaseops

Phase of Operations

Description: Selection made at Emergency Procedures element to set up section as phase of operation rather than by system.

Source paragraph: 7700G paragraph 3.3.5.1 and 3.3.5.1.1

Content Model: (intropara, genemerg, grndops, takeoff, inflight, landing, miscemerg)
+(figure | table | objmedia)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |

| | | | |
|-----------|-------------------------------------|----------|--|
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

phrase

Downgrade Phrase

Description: Identifies the text of the downgrade notice on the title page.

Source paragraph: 4.4

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

precaut

Precaution

Description: Identifies general safety precautions in the safety summary. The FOSI will automatically place a bullet to the left of each precaution.

Source paragraph: 4.5.10.1

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | warning | caution | precaut)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

preface

Preface

Description: Identifies the preface of the manual. This element is identical to the foreword and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: (para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp)*, tctolist, tmimpred?) +(figure | table)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

preentry

Primary Index Entry

Description: Used by author to identify primary entries that will be included in the index.

Source paragraph: 4.2.9.8

Content Model: (topic) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

premidno

Previous Technical Manual Identification Number (Not Used; Under Review)

Description: Identifies the previous technical manual identification number of the manual on the title page. This element is used only when the manual number has been changed. The FOSI will automatically generate the Formerly prefix preceding the former manual number.

Source paragraph:

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|---|
| security | (U C S N) N | | Identifies security level of the document |
| service | (AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD) | #IMPLIED | Defines the branch of service. |

prindex

Primary Index

Description: Identifies a primary alphabetical index topic in the manual.

Source paragraph: 4.2.9.8

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) - (secindex)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|-----------------|--|
| pridnbr | CDATA | #IMPLIED | Defines a unique identification number that allows an association between items tagged as primary index topics and those tagged as secondary index topics. |
| security | (U C S N) N | | Identifies security level of the document |

prtitle

Prime Title

Description: Identifies the title of the manual on the title page.

Source paragraph: 4.5.1.3e

Content Model: ((nomen, (modelno | partno | typedes | pslist | nsn)+, serno*) | subject)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

procedure

Procedure

Description: Procedure is a 'task' item in a checklist.

Source paragraph: 7700G paragraph 3.2.12.1

Content Model: ((title)?, (para | condition | clstep1 | ifthen)+) +(warning | caution | note)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| clrank | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. The order of the inclusion shall be included here. For example, if a procedure is to be included in the first grouping (by phase of flight or system), set clrank="1". If it goes with the second grouping, set clrank="2", etc. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used with this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |

| | | | |
|-----------|--|-----------------|--|
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |
| security | (U C S N) N | | Identifies security level of the document |

prtitle

Prime Title

Description: Identifies the title of the manual on the title page.

Source paragraph: 4.5.1.3e

Content Model: ((nomen, (modelno | partno | typedes | pslist | nsn)+, serno*) | subject)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

pslist

Part/Serial Number List

Description: Identifies a listing on the title page that corresponds a particular part number with associated serial numbers. This element could also be used to correspond model numbers with serial numbers, etc.

Source paragraph: 4.5.1.3.4

Content Model: (partno, serno+)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

pubdate

Publication Date

Description: Identifies the basic date of the manual on the title page.

Source paragraph: 4.5.1.16

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

randlist

Random List

Description: Identifies a random list. All items within the random list will appear unnumbered, on separate lines, in the order they were entered by the author.

Source paragraph: NONE

Content Model: (title?, item+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| prefix | CDATA | #IMPLIED | If prefix is used, the bullets will not appear that are generally formatted by the fosi. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|------------------------|----------|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the document |

ratd

Record of Applicable Technical Directives

Description: Identifies the record of applicable technical directives paragraph and the associated table.

Source paragraph: 4.5.9.4

Content Model: (ratdentry+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the document |

ratddesc

Record of Applicable Technical Directives Description

Description: Defines the description of the record of applicable technical directives paragraph and the associated table.

Source paragraph: 4.5.9.4

Content Model: (((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*), ratd?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

ratdentry

Record of Applicable Technical Directives Table Entry

Description: Defines each entry of the Record of Applicable Technical Directives Table.

Source paragraph: 4.5.9.4

Content Model: ((typeno, date?, title, ecpno?, dateinc?, remarks?)*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

rear

Rear Matter

Description: Identifies the rear matter of the manual.

Source paragraph: 4.2.9.6, 4.2.9.7, 4.2.9.8, & 4.6

Content Model: (glossary?, index, foldsect?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

numcols 1 | 2

Allows the author to define the page format as one or two columns for this section of the manual.

remarks

Remarks Entry

Description: Identifies an entry in the remarks column of the record of applicable technical directives.

Source paragraph: 4.5.9.4e

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

removepg

Remove Page Column Entry

Description: Identifies an entry within the Remove Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

revisdate

Revision Date

Description: Used in the List of Current Abbreviated Checklists to state the revision date of the checklist.

Source paragraph: 7700G paragraph 3.3.2.2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

revision

Revision

Description: Indicates changes made to the basic flight manual or abbreviated checklist in a safety supplement or operational supplement.

Source paragraph: 7700G paragraph 3.2.7

Content Model: (para0, (para | warning | caution | note | para0 | subpara1 | subpara2 | subpara3 | step1 | step2 | step3 | step4 | clstep1 | clstep2 | clstep3 | clstep4 | figure | table | procedure | condition)*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

revnum

Revision Number

Description: Identifies the revision number of the manual on the title page.

Source paragraph: 4.8

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

row

Row

Description: Identifies a row in a table.

Source paragraph: 4.2.7

Content Model: (entry | entrytbl)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-----------------------|---------|--|
| rowsep | %YESORNO; #IMPLIED | | Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators. |
| valign | TOP BOTTOM MIDDLE | | Defines the vertical alignment for cell contents. |

| | | |
|----------|-------------------|---|
| security | (U C S N) N | Identifies security level of the document |
|----------|-------------------|---|

safesum

Safety Summary

Description: Identifies the safety summary of the manual. The title is automatically generated by the FOSI.

Source paragraph: 4.5.10

Content Model: (para0+) +(figure | table | warning | caution | precaut)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |

| | | | |
|----------|--|-----------------|--|
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

safopsuppl

Safety and Operational Supplements

Description: Area of the Status Page that indicates the date and title of the supplements.

Source paragraph: 7700G Figure 2

Content Model: ((supplnum, date, shorttitle)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|-------------|
| label | CDATA | #IMPLIED | |

safsupp

Safety Supplement

Description: Selected at docfmsupp element level to chose safety supplement over operational supplement.

Source paragraph: None.

Content Model: suppfrent, suppbody

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

seal

Seal

Description: Department of the Navy Seal, with command identifier.

Source paragraph: 4.5.1.5

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

secentry

Secondary Index Entry

Description: Used by author to tag data for inclusion in the index as a secondary topic

Source paragraph: 4.2.9.8

Content Model: topic

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

secindex

Section Index

Description: Identifies a secondary alphabetical index topic in the manual.

Source paragraph: 4.2.9.8

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -
(secindex)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| pridnbr | CDATA | #IMPLIED | Defines a unique identification number that allows an association between items tagged as primary index topics and those tagged as secondary index topics. |

section

Section

Description: Identifies a section of the manual, the next further breakdown of a chapter.

Source paragraph: 4.2.9.4

Content Model: (title, para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

sectoc

Section Table of Contents

Description: Auto-generated table of contents for each section in the basic flight manual. Created by OmniMark.

Source paragraph: 7700G paragraph 3.3.2.4

Content Model: ((ptitle)*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|----------------|-------------|
| autobuild | CDATA | #CONREF | |

| | | | |
|-----------|----------------------|-----------------|--|
| address | CDATA | #IMPLIED | |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |

seeto

See T.O.

Description: Used on the title page for Section IV, Mission Crew Duties, when the duties are found in a separate technical manual.

Source paragraph: 7700G paragraph 3.3.6

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

seqlist

Sequential List

Description: Identifies a sequential list. All items within the sequential list will appear numbered, on separate lines, in the order they were entered by the author.

Source paragraph: MIL-PRF-28001

Content Model: (title?, item+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---|-----------------|--|
| numstyle | ALPHAUC ALPHALC ARABIC ROMANUC ROMANLC | | Defines the type of enumeration on the sequential list. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the document |

seqno

Sequence Number

Description: Defines the sequence number for a hazard warning.

Source paragraph: 4.3.10.1

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

serno

Serial Number

Description: Identifies serial numbers of the equipment on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|-----------------|---|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the document |

shorttitle

Short Title

Description: Used in the Status Page for changes to indicate the title of safety and operational supplements.

Source paragraph: 7700G Figure 2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

sigblock

Signature Block

Description: Provides signature block.

Source paragraph: MIL-STD 38784A DRAFT

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

spanspec

Span Specification

Description: Used to join two or more columns in a table. Span specifications are similar to column specifications (<colspec>) except that they describe areas of the table that can be spanned (joined) using a table entry (<entry>). For example, a three-column table may have columns named 1, 2, and 3 respectively. A span named 23 may be declared using spanspec. When spanname=23 is used on an entry, that entry would occupy the space in both columns 2 and 3.

Source paragraph: MIL-PRF-28001 8.4.5.3

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---|------------------|--|
| namest | NMTOKEN | #REQUIRED | The name of the first column of the set of columns that you want to span. |
| nameend | NMTOKEN | #REQUIRED | The name of the last column of the set of columns that you want to span. |
| spanname | NMTOKEN | #IMPLIED | Defines a unique name for the span. |
| align | LEFT RIGHT CENTER JUSTIFY CHAR | | Allows the author to align text within the cell. |
| charoff | NUTOKEN | #IMPLIED | Determines the distance the cell content should offset from the horizontal alignment character. |
| char | CDATA | #IMPLIED | Defines the alignment character that can be used to align values within a column. |
| colsep | %YESORNO; | #IMPLIED | Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators. |
| rowsep | %YESORNO; | #IMPLIED | Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators. |

spins

Spins

Description: Area of Section VI, Flight Characteristics

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.9

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |

| | | | |
|-----------|-------------------------------------|----------|--|
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

stalls

Stalls

Description: Area of Section VI, Flight Characteristics.

Source paragraph: 7700G paragraph 3.3.8 and 3.3.8.7

Content Model: (para0+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |

| | | | |
|----------|-----------------|---|--|
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) | N | Identifies security level of the element. |

status

Status

Description: Tag used to denote whether a supplement is incorporated, rescinded, or deleted on the Status Page for change.

Source paragraph: 7700G Figure 2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

statuspge

Status Page for Changes

Description: Provided as part of the change package.

Source paragraph: 7700G paragraph 3.2.8.1

Content Model: (para, aircrewfm?, checklists?, safopsuppl?, suppllist?, estdistr?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

step1

First Level Procedural Step

Description: Identifies a first level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: (note?, para, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| | | | |

| | | | |
|-----------|--|-----------------|---|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process |
| oci | NUMBER | 0 | Observable Critical Item |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |

step2

Second Level Procedural Step

Description: Identifies a second level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: (note?, para, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|----------|---|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.. A **FCP** symbol will appear when set equal to 1. |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process |
| oci | NUMBER | 0 | Observable Critical Item |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |

step3

Third Level Procedural Step

Description: Identifies a third level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: (note?, para, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|-----------------|---|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process |
| oci | NUMBER | 0 | Observable Critical Item |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |

step4

Fourth Level Procedural Step

Description: Identifies a fourth level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: (note?, para, warning?, caution?, note?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|-----------|--|-----------------|---|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness critical Processes. A **HCP** symbol will appear when set equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process |
| oci | NUMBER | 0 | Observable Critical Item |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference to this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Insert Change Level |
| delchlvl | NMTOKEN | #IMPLIED | Used to generate change packages - Delete Change Level |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Allows you to specify the status of this element. |
| revchg | NUMBER | 0 | Used to generate a revision |

subfig

Subfigure

Description: Identifies a subfigure. This element is used for multisheet illustrations, each sheet being a subfigure. The FOSI will automatically generate the sheet count (e.g Sheet 1 of 10, Sheet 2, etc.)

Source paragraph: 4.2.4.2

Content Model: ((graphic, legend?) | figtable)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | | |
|----------|--|-----------------|--|
| orient | PORT LAND1 | | Defines the orientation of the figure. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

subject

Subject

Description: Identifies the prime title of the manual on the title page.

Source paragraph: 4.5.1.3.4

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

subjinfo

Subject Information (Not Used; Under Review)

Description: Identifies subject information that appears at the top of every column in a chapter. This first subjinfo tag in a chapter should be placed after the chapter tag or the first section tag (if used). Additional subjinfo tags have no restrictions on placement and should be used wherever the information changes.

Source paragraph:

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|------------------|---|
| subjup | CDATA | #REQUIRED | Not currently supported by the FOSI. Element and attributes are under review. |
| subjlwr | CDATA | #REQUIRED | Not currently supported by the FOSI. Element and attributes are under review. |
| infoup | CDATA | #REQUIRED | Not currently supported by the FOSI. Element and attributes are under review. |
| infolwr | CDATA | #REQUIRED | Not currently supported by the FOSI. Element and attributes are under review. |

subobjmedia

Sub Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph:

Content Model: object

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

subpara1

First Subordinate Paragraph

Description: Identifies a first subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: (title,note?, (para, warning?, caution?, note*)*, (step1, step1+)?), sub-para2*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |

| | | | |
|----------|--|-----------------|--|
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

subpara2

Second Subordinate Paragraph

Description: Identifies a second subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: (title?,note?, (para, warning?, caution?, note*)*,(step1, step1+)?), subpara3*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |

| | | | |
|-----------|--|-----------------|--|
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

subpara3

Third Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: (title?,note?, (para, warning?, caution?, note*)*,(step1, step1+)?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |

| | | | |
|-----------|--|-----------------|--|
| fcf | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

subtitle

Subtitle

Description: Identifies the subtitle of the manual on the title page.

Source paragraph: 4.5.1.3.5

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

supersed

Supersedure Notice

Description: Identifies the supersede notice on the title page.

Source paragraph: 4.5.1.6

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

suppl

Supplement Notice

Description: Identifies the supplement notice on the title page.

Source paragraph: 4.5.1.8

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

suppbod

Supplement Body

Description: Body tag for safety and operational supplements.

Source paragraph: None. Developed for FOSI code.

Content Model: (revision+, abbrchklist?, statuspge) +(newpage)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| |
|------|
| NONE |
|------|

suppfront

Supplement Front Matter

Description: Front tag for safety and operational supplements.
Source paragraph: None. Developed for FOSI code.
Content Model: (suppidinfo)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

suppidinfo

Supplement Idinfo

Description: Idinfo tag for safety and operational supplements.
Source paragraph: None. Developed for FOSI code.
Content Model: (tmidno+, pretmidno*, doctype?, prtitle, subtitle?, (mfr, contractno+)?, supersed?, note?, emerprocnot?, discl?, distrib, expcont?, destr?, copyright*, aircrewnot, authnot, downgrd?, pubdate?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

supplist

Supplements List

Description: Incorporated, rescinded, or deleted supplements. Part of the Status Page used for changes.
Source paragraph: 7700G paragraph 3.2.7.3 and Figure 2.
Content Model: ((supplnum, date, status)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|-------------|
| label | CDATA | #IMPLIED | |

supplnum

Supplement Number

Description: Number of the safety or operational supplement that is incorporated, rescinded, or deleted.

Source paragraph: 7700G Figure 2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

symsect

Symbol Paragraph

Description: Identifies the paragraph used to define symbols (e.g ESDS symbol) and the associated list.

Source paragraph: 4.5.9 & 4.3.4

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-
paral*), (symtitle?, (term, def)+))

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|------------|---------------|-----------------|---|
| rtermwidth | NUOKEN | 2.75IN | Allows you to set the right term width. |
| ltermwidth | NUOKEN | 0.75IN | Allows you to define the left term width. |
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |

| | | | |
|-----------|-------------------------------------|----------|--|
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

symtitle

Symbol Paragraph

Description: Identifies the title used to define symbols (e.g ESDS symbol) and the associated list.

Source paragraph: 4.5.9 & 4.3.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

sysemerg

System Emergency Procedures

Description: Area of the system arrangement of Section III, Emergency Procedures.

Source paragraph: 7700G paragraph 3.3.5.2 and 3.3.5.8.7

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |

| | | | |
|----------|--|-----------------|--|
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| deltype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

system

System Arrangement

Description: Selection made at the Emergency Procedures element to set up the section by system.

Source paragraph: 7700G paragraph 3.3.5.1 and 3.3.5.2

Content Model: (intropara, genemerg, sysemerng, miscemerng)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |

| | | | |
|-----------|--|-----------------|--|
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

table

Table

Description: Identifies a table.

Source paragraph: 4.2.7

Content Model: (title, tgroup+) -(figure | table | foldout) +(tfoot | tfnref | tfndisplay)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------|-----------------|-------------|
| tabstyle | NMTOKEN | #IMPLIED | |

| | | | |
|-----------|--|-----------|--|
| frame | TOP BOT- TOM TOPBOT ALL SIDES NONE | ALL | |
| colsep | NUMBER | 1. | Toggle switch to indicate if column separators are used. |
| rowsep | NUMBER | 1. | Toggle switch to indicate if row separators are used. |
| orient | PORT LAND1 LAND2 | PORT | Defines orientation of table on the page. %verified; |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| security | (U C S N) N | | Identifies security level of the document |
| pgwide | NUMBER | 1. | Specifies if table stretches across the entire page. |
| cellcont | CONTINUED CONT | CONTINUED | Specifies whether cell contents can be continued. |
| ID | ID | #IMPLIED | Provides means to specify an ID number for the table. |
| footnotes | PAGE END | #IMPLIED | Allows you to specify whether table footnotes appear at the end of the table or at the end of the page. |
| leftind | CDATA | #IMPLIED | Specifies left indent of the table in relationship to the page. |
| rightind | CDATA | #IMPLIED | Specifies right indent of the table in relationship to the page. |
| leftmar | NUTOKEN | #IMPLIED | Specifies left margin of the table. |
| rightmar | NUTOKEN | #IMPLIED | Specifies left margin of the table. |
| topmar | NUTOKEN | #IMPLIED | Specifies left margin of the table. |
| botmar | NUTOKEN | #IMPLIED | Specifies left margin of the table. |
| mindepth | NUTOKEN | #IMPLIED | Specifies the minimum depth of the table. |
| pgdeep | NUMBER | 0 | Allows you to specify whether that table is equal to the depth of the page. |
| applicref | IDREFS | #IMPLIED | Specifies all IDs of elements or data items that have an applicable reference. |

| | | | |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |

tablelist

List of Tables

Description: Identifies the list of tables in the manual. This information is automatically compiled by the FOSI. If this element is not used, no list of tables will appear in the manual.

Source paragraph: 4.5.8

Content Model: (tabno, title, pageno)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |
| security | (U C S N) N | | Identifies security level of the document |

tabmat

Table Material

Description:

Source paragraph: 4.3.9

Content Model: (tgroup+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

tabno

Table Number

Description: Identifies the Table number within the table list when the table list is manually tagged.

Source paragraph: NONE

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

takeoff

Takeoff Emergency Procedures

Description: Area of phase of operations arrangement of Section III, Emergency Procedures.

Source paragraph: 7700G paragraph 3.3.5.1.1 and 3.3.5.7

Content Model: (para0 | procedure)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|--|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts are identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedure. All paragraphs which address nuclear survivability *** NSP *** parts are identified by the ncp symbol by setting attribute equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address fracture critical processes are identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process are identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. A **HCI** symbol will appear when set equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes are identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items are identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |

| | | | |
|----------|--|-----------------|--|
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

tasks

Tasks

Description: Identifies the tasks for each crew member listed in the Coordinated Procedures Table

Source paragraph: 3.2.12.3

Content Model: (newpos1?, newpos2?, newpos3?, newpos4?, newpos5?, cmbr1?, cmbr2?, cmbr3?, cmbr4?, cmbr5?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. |

tbody

Table Body

Description: Identifies the body of a table (e.g. material below the boxheads).

Source paragraph: 4.3.9

Content Model: (row+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------------------------------|---------|--|
| valign | TOP MIDDLE BOTTOM | | Defines the vertical alignment of data within a cell of the table. |

tctolist

Time Compliance Technical Orders Paragraph

Description: Identifies the time compliance technical orders paragraph and the associated table.

Source paragraph: 4.5.9.3

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?)?, sub-para1*, tctotbl?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|----------------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |

| | | | |
|----------|--|-----------------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

tctono

Time Compliance Technical Order Number

Description: Identifies an entry in the TCTO Number column in the TCTO table.

Source paragraph: 4.5.9.3

Content Model: (#PCDATA) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

tctorow

Time Compliance Technical Orders Row

Description: Identifies a row in the time compliance technical orders table.

Source paragraph: 4.5.9.3

Content Model: (tctono, title, date)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|----------|--|
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

tctotbl

Time Compliance Technical Order Table

Description: Identifies the table that lists all TCTOs applicable to the manual. The FOSI will automatically generate the table title and the column headings (boxheads).

Source paragraph: 4.5.9.3

Content Model: (tctorow+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------------------------------|----------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |

| | | | |
|----------|--|-----------------|---|
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

term

Term

Description: Identifies an entry in the term portion of a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: 4.3.4

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

tfnid

Table Footnote Id

Description: This element is for placing a footnote in a 38784 table model. A superscript will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: 4.2.7.5

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------------------|------------------|---|
| id | ID | #REQUIRED | This allows you to identify each element and later reference it by its id value. |
| tfntype | NUM AL-PHA SYM | | Defines the type of symbol used to indicate a table footnote. |
| tfnsymbol | CDATA | #IMPLIED | Allows you to define the actual symbol to serve as a table footnote reference. |
| tfnval | CDATA | #IMPLIED | Defines the text value of the reference. The actual data to be generated at the bottom of the table should be placed with this attribute. |

tfnref

Table Footnote Reference

Description: This element is for referencing a footnote in a 38784 table model that was created with a table footnote id. The superscript that was generated from the table footnote id will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: 4.2.7.5

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|------------------|--|
| xrefid | IDREF | #REQUIRED | Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual. |

tfoot

Table Foot

Description: The foot of the table.

Source paragraph: 4.2.7.5

Content Model: (tfnid*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

tfndisplay

Table Footnote Display

Description: This element is for displaying footnotes in a 38784 table model. Footnotes to tables will be displayed at the end of the table. This element should be placed in a span in the last row of the table.

Source paragraph: 4.2.7.5

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

tbody

Table Group

Description: Identifies a table group, which consists of a table heading (boxheads) and a table body.

Source paragraph: 4.2.7

Content Model: (colspec*, spanspec*, thead?, tbody)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---|------------------|--|
| cols | NUMBER | #REQUIRED | Defines the number of columns within the table. |
| colsep | %YESORNO; #IMPLIED | | Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators. |
| rowsep | %YESORNO; #IMPLIED | | Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators. |
| align | (LEFT RIGHT CENTER JUSTIFY CHAR) | LEFT | Allows the author to align text within the cell. |
| leftind | CDATA | #IMPLIED | Defines the left indent of text within the cell. |
| rightind | CDATA | #IMPLIED | Defines a right indent of the text within the cell. |
| leftmar | NUTOKEN | #IMPLIED | Defines the left margin of the cell. |
| rightmar | NUTOKEN | #IMPLIED | Defines the right margin of the cell. |
| topmar | NUTOKEN | #IMPLIED | Defines the top margin of the cell. |
| botmar | NUTOKEN | #IMPLIED | Defines the bottom margin of the cell. |
| mindepth | NUTOKEN | #IMPLIED | Defines the minimum depth of the table. |
| charoff | NUTOKEN | #IMPLIED | Determines the distance the cell content should offset from the horizontal alignment character. |
| char | CDATA | #IMPLIED | Defines the alignment character that can be used to align values within a column. |

thead

Table Heading (Boxheads)

Description: Identifies a table heading (boxheads). The table heading (boxheads) repeat when the table breaks across a column or page.

Source paragraph: 4.2.7.3

Content Model: (colspec*, row+) -(entrytbl)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
|-----------|------|---------|-------------|

| | | |
|--------|--------------------------------|---|
| valign | TOP MID-DLE BOT-TOM | Defines the vertical alignment of text within a cell. |
|--------|--------------------------------|---|

title

Title

Description: Identifies a title (e.g. chapter, paragraph, table, etc.). The title should be tagged exactly as it is to appear in the table of contents. Titles that are placed on tables will appear in the List of Tables, and titles that are placed on figures and figure tables will be placed in the List of Illustrations. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: MIL-STD-38784

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------------------------|----------|---|
| security | (U C S N) | N | Identifies security level of the document |

tmidno

Technical Manual Identification Number

Description: Identifies the technical manual identification number. When used on the title page (<idinfo>), it will cause the technical manual number to appear on the title page and at the top of each page in the manual. When used in the list of related publications (<lrp>), will cause the technical manual number to be placed in the Publication Number column.

Source paragraph: 4.2.1.5 & 4.5.9.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| service | (AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD) | #IMPLIED | Defines the branch of service. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |

| | | | |
|----------|--|-----------------|--|
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

tmimprep

Technical Manual Improvement Report

Description: Identifies the technical manual improvement report paragraph.

Source paragraph: 4.5.9

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|---------------|-----------------|---|
| emergency | NUMBER | 0 | Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1. |
| id | ID | #IMPLIED | Allows author to designate a unique paragraph ID for use with external and cross references. |
| esds | NUMBER | 0 | Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1. |
| nsp | NUMBER | 0 | Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1. |
| fcp | NUMBER | 0 | Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1. |
| hcp | NUMBER | 0 | Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1. |
| hci | NUMBER | 0 | Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1. |
| ocp | NUMBER | 0 | Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1. |
| oci | NUMBER | 0 | Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1. |
| applicref | IDREFS | #IMPLIED | Allows you to assign an applicable reference |

| | | | |
|-----------|--|-----------------|--|
| verdate | CDATA | #IMPLIED | Identifies the date the element was verified. |
| verrem | CDATA | #IMPLIED | Provides a place for the author to make remarks about the verification of the element. |
| verstatus | (UNVER VER) | UNVER | Identifies verification status of the element. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the element. |

tochgdate

T.O. Change Date

Description: Change Date for aircrew flight manual or flight crew checklists on the status page.

Source paragraph: 7700G Figure 2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

tochgnum

T.O. Change Number

Description: Change number for aircrew flight manual or flight crew checklists on the status page.

Source paragraph: 7700G Figure 2

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

tonum

T.O. Number

Description: T.O. number for the aircrew flight manual or flight crew checklists on the status page.

Source paragraph: 7700G Figure 2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

topic

Index topic

Description: Used by author to tag topics that will be appear in the index. Used as subelement for preentry and secentry.

Source paragraph: 4.2.9.8

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|--|
| page | CDATA | #IMPLIED | Defines the page where the index topic occurs in the manual. |

tpdr

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.

Source paragraph: 4.5.9
Content Model: (tpdrtbl | none)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

tpdrlocation

Technical Publications Deficiency Report Location

Description: Identifies an entry in the Location column of the technical publications deficiency report list.
Source paragraph: 4.5.9
Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

tpdrno

Technical Publications Deficiency Report Number

Description: Identifies an entry in the Report Control Number column of the technical publications deficiency report list.
Source paragraph: 4.5.9
Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

tpdrtbl

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.
Source paragraph: 4.5.9
Content Model: (activity, tpdrno, tpdrlocation)+

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| id | ID | #IMPLIED | This allows you to identify each element and later reference it by its id value. |
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |

typedes

Type Designation

Description: Identifies a type designation on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1B

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

typeno

Directive Type and Number

Description: Identifies an entry in the Type/No column of the record of applicable technical directives table.

Source paragraph: 4.5.9.4a

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
| graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp |
acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure
| table | foldout)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|---------|---|
| security | (U C S N) N | | Identifies security level of the document |

verbatim

Verbatim Text

Description: A verbatim element is used to format computer examples or similar text in a typewritten emulation mode. Formatting follows 'asis' quadding with monospaced font.

Source paragraph: MIL-PFR-28001C, B.3.14

Content Model: CDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------------------|----------|--|
| allowbrk | NUMBER | 1 | Defines if a break can be inserted into verbatim text. |
| security | (U C S N) N | | Identifies security level of the document |

verstat

Verification Status Page

Description: Identifies the verification status page in the manual. This information is automatically compiled by the FOSI. This element should not be used if a verification status page is not desired.

Source paragraph: 4.5.4

Content Model: (tabmat?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

vollep

Volume List of Effective Pages

Description: Identifies the volume List of Effective Pages.

Source paragraph: 4.2.9.1

Content Model: (volleppcontents)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

volleppentry

Volume LEP Entry

Description: LEP entry that should appear in the volume LEP.

Source paragraph: 4.5.3

Content Model: volleppage, volleppchg

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

volleppage

Volume LEP Page Number

Description: Volume Page Number for each entry in the VOLLEP.

Source paragraph: 4.5.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

volleppchg

Volume LEP Change Number

Description: Volume Change Number for each entry in the VOLLEP.

Source paragraph: 4.5.3

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

volcontents

Volume Contents

Description: Identifies a volume contents.

Source paragraph: 4.2.9.1

Content Model: (#PCDATA)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |

volilluslist

Volume Illustration List

Description: Identifies a volume list of illustrations.

Source paragraph: 4.2.9.1

Content Model: (figno, title, pageno)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |

vollecontents

Volume Contents

Description: Identifies the volume.

Source paragraph: 4.2.9.1

Content Model: (volleentry+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|-----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |
| lepcount | CDATA | #IMPLIED | Defines the number of pages in the lep for each volume. |

voltablelist

Volume Table List

Description: Identifies a volume list of tables.

Source paragraph: 4.2.9.1

Content Model: (tabno, title, pageno)*

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--------------|----------------|---|
| autobuild | CDATA | #CONREF | This attribute should be set equal to 1. when the acronymlist is autogenerated. |

volnot

Volume Notice

Description: Identifies the volume notice on the title page.

Source paragraph: 4.2.9.1

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

volnum

Volume Number

Description: Identifies the volume number on the title page.

Source paragraph: 4.2.9.1

Content Model: #PCDATA

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|------|---------|-------------|
| NONE | | | |

volume

Volume

Description: Identifies a volume.

Source paragraph: 4.2.9.1

Content Model: ((front | auxfront), body, rear?)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| label | CDATA | #IMPLIED | Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired. |
| sssn | CDATA | #IMPLIED | System, Subsystem, or Subject Number can be assigned to this element. |
| indexid | CDATA | #IMPLIED | Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| security | (U C S N) N | | Identifies security level of the document |
| docid | CDATA | #IMPLIED | Allows for the author to define an identification number for the document. |
| docstat | (REVISION CHANGE PRELIM DRAFT FORMAL) | PRELIM | Author can stipulate what form the manual is in. |
| verstatpg | (VER UN-VER) | VER | Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail. |
| Index | NUMBER | 0 | Indicated whether an index is included in the manual. Attribute should be set to 1 when an index is present. Use of this attribute will affect the level of detail in the TOC |

| | | |
|-----------|---|---|
| service | (AF NAVAIR #REQUIRED NAVSEA SPAWARS ARMY MC DLA CG DOD) | Defines the branch of service. |
| volpages | %YESORNO; 0 | Indicates whether the page numbers within the volume use the volume number prefix. Zero indicates standard page numbers. 1. indicates a volume prefix will be used. |
| resetnbrs | %YESORNO; 1 | Allows you to reset chapter numbers when continuing to a second or subsequent volume. 1. will reset chapter numbers back to 1. Zero will continue with the chapter numbers. |

warning

Warning

Description: Identifies a WARNING in the manual. Multiple warning tags may be used only when it is desired to change the warning icon (standard or hazardous warning graphic).

Source paragraph: 4.3.10

Content Model: (icon?, para*) -(randlist | deflist | seqlist | figure | table | foldout | warning | caution | precaut)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------------------|----------|--|
| cl | NUMBER | 0 | Attribute to flag element for inclusion by checklist extraction scripts. Not used on this element. |
| delttype | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

warnpage

Warning Page

Description: Identifies the warning page(s) of the manual.

Source paragraph: 4.5.2

Content Model: (wpgentry+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |

wpgentry

Warning Page Entry

Description: Identifies an individual warning on the warning page(s).

Source paragraph: 4.5.2

Content Model: (title, para+)

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|--|-----------------|--|
| warnbox | NUMBER | #IMPLIED | Allows you to specify the appearance and size of the warning box. |
| deltypes | DELETE REAL RESERVE NA | #IMPLIED | Used to generate change packages - Delete Type |
| inschlvl | NMTOKEN | #IMPLIED | Used during the change package process to indicate the element was inserted at the change level indicated. |
| delchlvl | NMTOKEN | #IMPLIED | Used during change package process to indicate the element was deleted at the change level indicated |
| status | EMPTY DELETED RESERVED NOTAPP | #IMPLIED | Used during the change package process to indicate the current status of the element. |
| revchg | NUMBER | 0 | Toggle between a revision or a change. Attribute is set to 1 to indicate a revision. |
| titlefont | (10PT 14PT) 14PT | | Specifies the font size choices available for a warning page entry. |
| line | NUMBER | #IMPLIED | Specifies whether a line should appear between warning page entries. |

xref

Cross-reference

Description: Identifies a cross-reference to a paragraph, figure, table, etc.

Source paragraph: 4.3.1

Content Model: EMPTY

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

| Attribute | Type | Default | Description |
|-----------|-------------------------|-----------------------|--|
| xrefid | IDREF | #REQUIRED | Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual. |
| HyTime | NAME #FIXED | CLINK | Used in combination with HyTime to establish contextual link. |
| HyNames | CDATA #FIXED | LINKEND XREFID | Used in combination with HyTime to establish contextual link. |

